

PROP 65 WARNING: This product can expose you to chemicals including Formaldehyde, which is known to the State of California to cause cancer. For more information go to www. P65Warnings.ca.gov.



Tools Required _____

- Safety Glasses, gloves, and dust maks
- Poster board or butcher paper
- Poster board or butcher paper
- Brake cleaner or other degreaser
- Pre-paint cleaner, isopropyl alcohol or other non-residue cleaner

Applications _____

- Interior Trim Panels
- Speakers
- Harnesses
- Linkages
- Harnesses
- License plate brackets

WANT TO BE FEATURED? FOLLOW, POST, TAG: @HEATSHIELDPRODUCTS

#RACETESTED

Installation Tips _____

A little db Gasket will go a long way! Only small pieces of this material are necessary to prevent squeaks, rattles and buzzes from occurring.

Take a moment to measure the surface to be treated to make sure enough db Gasket is available to complete the installation.

Be sure db Gasket and panel are above 65°F, so adhesive makes good contact and cures properly

Installation Steps _____

- 1. Put on safety glasses, dust mask, and gloves
- 2. Be sure to clean the surface of the components by cleaning and degreasing them. Give the panel one final wipe with isopropyl alcohol, pre-paint cleaner, ammonia based aerosol glass cleaner, or other non-residue leaving cleaner.
- 3. Measure twice, cutting and fitting the db Gasket to be installed first.
- 4. Make sure the installation of db Gasket will not impede the proper operation of any mechanical component.
- 5. Remove the paper release liner and apply the db Gasket onto the surface.
- 6. Hold firmly for 30 seconds.
- 7. Done!





